

PRODUCT INFORMATION

PARASET POLYMERIC SAND

PARASET POLYMERIC SAND

This is a specially formulated mixture of ASTM C-144 graded sand and special additives to help sand stabilization for flexible and semi-rigid pavement systems using segmental pavers.

FEATURES AND BENEFITS:

- ◇ Just sweep into paver joints and spray with water.

PREPARATION:

- ◇ Place a base of sand using Paragon Pack Base Sand (follow bag instructions for installation).
- ◇ Place a bed of Paragon Paver Finish Sand to level pavers (follow bag instructions for installation).
- ◇ Use Paragon Paraset Polymeric Sand to lock down the pavers.

PLACEMENT:

- ◇ Clean surface of all debris or other material.
- ◇ SURFACE MUST BE COMPLETELY DRY.
- ◇ Pour Paraset Polymeric Sand in small piles about 12 inches apart on top of pavers. Sweep into and fill all points to bottom of the paver chamber.

- ◇ Avoid sweeping Paraset Polymeric Sand too far.
- ◇ Repeat as necessary to fill all joints.
- ◇ Compact all paver and joints with a tamp or vibrating plate.
- ◇ Fill and tamp or vibrate until all joints are filled.
- ◇ Using a fine broom and leaf blower, remove all excess material from surface. This is important to prevent surface staining.
- ◇ Set pavers and joints with a fine mist (avoid spraying into joints or flooding). Spray until there is a light water retention (approximately 20-30 seconds).
- ◇ Repeat 2-3 times at 10 minute intervals to allow water penetration.
- ◇ Do not walk on for a minimum of 4 hours.
- ◇ Do not open to traffic for 24 hours.
- ◇ Do not use if rain is forecasted within 24 hours.
- ◇ Do not lay pavers when temperatures are below 40°F (4°C).
- ◇ This product is for locking down and securing pavers; it is not a mortar.

EACH 50# BAG COVERS:

Coverage in Sq. Feet	Coverage in Sq. Meters	Width of Joints in Inches	Width of Joints in mm
50-80 Sq. Feet	4.6-7.4 Sq. Meters	1/8" Wide	3.1 mm Wide
18-25 Sq. Feet	1.9-3.7 Sq. Meters	3/8" Wide	9.3 mm Wide